\sim Self Check when Printing \sim



In order to use the machine stably, please check the followings before printing. If a setting is wrong, Image defects might result.

	Is the environment suitable fo	r printing?		
		Available temp.	20 to 30 °C (68 to 86° F)	
		Humidity	35 to 60 % Rh (No condensation)	
		Guaranteed temp.	20 to 25 °C (68 to 77° F)	
POINT	Is the machine's lamp flashing Flashing red : Error has Lit seady red : Error (S GIf an error displays, p	occurred (STEM HALT) has oc	curred ror code list in the operation manual a	and take appropriate action.
	Did you check Print Head Height?			
	When bi-directional printing, be sure to correct the dot position after altering the print head height.			
		Range	Head Height	
		Low	2.0 mm (Default Setting)	
		Middle	2.5 mm	
		High	3.0 mm	
POINT	양 Please alwa 양 Please set l • When adjusting from the front	ays use at least two p Pinch Rollers as symmetry ler guide mark reguide mark to the pinch roller guide marks.	Metrically as possible. • When adjusting from the read	
	If the torque limiter is adjus (3 The slack may o	ot be taken up firmly	ne media	0% of the maximum
POINT	Did you check Test Print?	mperature according ern to check that the or nozzle missing).	y to the characteristics of the media yo ere are no discharging defects such as	
		Good example	Bad example Deflection Nozzle co	ogging
	Did you adjust Media Correction and Drop Position? Please adjust Media Correction (the media feed amount) and Drop Position to match the type of media you are using. ③ Please adjust the drop position only when bi-directional printing			
	Media Correction (the media feed an	iount)	Drop.POS Correct (Correct)	cts the drop position for bi-directional printing)
	Second band	, Media feed		Media feed direction
			The drop position of	