## ~Self Check when Printing~



## In order to use the machine stably, please check the followings before printing. If a setting is wrong, Image defects might result.

POINT Is the environment suitable for printing?

	Available temp.	20 to 30 °C (68 to 86° F)
	Humidity	35 to 60 % Rh (No condensation)
	Guaranteed temp.	20 to 25 °C (68 to 77° F)

POINT

Is the machine's lamp flashing red or lit red?

Flashing red: Error has occurred

Lit seady red: Error (SYSTEM HALT) has occurred

③If an error displays, please refer to the error code list in the operation manual and take appropriate action.

POINT

Did you check Print Head Height?

When bi-directional printing, be sure to correct the dot position after altering the print head height.

Range	Head Height
L range	2 mm (Default Setting)
M range	2.5 mm
H range	3 mm


POINT


Did you check Pinch Roller positions?


Please adjust the pinch roller positions to suit the width of the media being used.

- F Please always use at least two pinch rollers.
- (\*\* Please set Pinch Rollers as symmetrically as possible.

## When adjusting from the front







POINT


Did you check Torque Limiter for Take-up?

If the torque limiter is adjusted too weak;

☐ The media can not be taken up firmly

If the torque limiter is adjusted too strong;

The slack may occur depending on the media and cause influence on the image quality








O POINT

Did you check Test Print?

Please check a test pattern to check that there are no discharging defects such as nozzle clogging (slight touching of ink or nozzle missing).





POINT

Did you adjust Media Correction and Drop Position?

Please adjust Media Correction and Drop Position to match the type of media you are using.

③ Please adjust the drop position only when bi-directional printing

