



Wall preparation

The base surface should be carefully prepared:

- Remove all old wallpaper – to remove the remains of old paste try using a squirting bottle with water and a few squirts of washing up liquid. This works perfectly well on most wallpaper paste residue.
- Remove peeling paint remnants
- Re-plaster and sand down any rough surfaces – although the glass textile products will cover small cracks and uneven surfaces.
- Clean with a damp cloth, leave walls to dry completely before wallpapering.

SiHL non-prepasted products

We recommend the use of Metylan pastes (standard non-woven wallpaper paste) – or similar solvent-free products (solvent based / or dispersion pastes can result in the removal of inks)

We recommend the use of protective gloves (soft cotton) when wallpapering to protect the inks.

- Paste the wall / or surface → non-woven does not need to soak the paste into it before hanging.
- Hang the way one would hang any non-woven wallpaper – either butt joint or double-seam cutting the panels.
- Use a damp cloth to remove any excess wallpaper paste from the media.

SiHL prepasted products

We recommend the use of protective gloves (soft cotton) when wallpapering to protect the inks.

Before hanging the following is required:

- printed, cut panels
- water bath to soak the panels
- Submerge the entire rolled up cut panel into water and soak for approx. 2 mins, to ensure that all paste is activated and unravel the panel slightly under water.
- Hang the way one would hang any other non-woven wallpaper – either butt joint or double-seam cutting the panels.
- Use a damp cloth to remove any excess wallpaper paste from the media.